



- | | | |
|--------|--------|--------|
| 2x(12) | 2x(26) | 2x(27) |
| 4x(29) | 2x(30) | 2x(31) |
| 1x(39) | 1x(40) | 1x(47) |
| | 1x(48) | |

B021A

Ausgabe Issue 2000-1		Bild Nr. Picture No B021A		SWING 45		SWING 45		Seite Page 8	
Pos. Fig.	Anzahl/Quantity			Artikel Nr. Part No	Bezeichnung	Description	Satz Kit	Anmerkung Notes	
	1			1117-3006-02	Chassie	Chassis			
	2			1117-3009-01	Radplatte	Wheel plate			
	3			1117-3010-01	Radplatte	Wheel plate			
	4			1117-3011-01	Radachse	Wheel axle			
	5			1111-3238-01	Rad	Wheel			
X	6			1117-3225-02	Nabenkapsel-weiß	Hub cap-white			
	7			1117-3007-01	Leitschiene-vordere	Baffle-front			
X	8			1117-3223-01	Ansatzbolzen	Shoulder bolt			
X	9			1117-3224-02	Nabenkapsel-weiß	Hub cap-white			
	10			1117-1161-01	Radschutz	Wheel protection			
	11			1117-3008-01	Leitschiene-hintere	Baffle-rear			
	12	14		9836-9516-12	Schraube	Screw			
	13			1117-1156-02	Klappe-schwarz	Rear flap-black			
	14			1117-1143-01	Achse	Shaft			
	15			1117-1126-01	Feder	Spring-rear flap			
	16			1117-1155-02	Klapphalterung-schw.	Flap holder-black			
	17			1117-1135-02	• Deckel-schwarz	• Cover-black			
	18			9987-5251-12	Schraube	Screw			
	19			1117-1065-01	Tellerfeder	Spring washer			
	20			1111-3163-01	Rad	Wheel			
	21			1117-3012-01	Lagerbuchse	Wheel bush			
	22			1117-1364-01	Schraube	Screw			
	23			9600-0014-00	Keil	Key			
X	24			1111-9703-01	Messer	Blade			
	25			1117-1131-01	Mutter	Nut			
	26			9699-0028-02	Scheibe	Flat washer			
	27			9898-0845-12	Schraube	Screw			
	28			1117-3030-01	Montagesatz	Assy kit			
	29			9579-0008-00	Kabelhalter	Cable holder			
X	30			1117-3194-01	Verriegelungsrads	Locking knob			
	31			9799-0831-02	Mutter	Nut			
	32			1117-1149-01	Führungsholm-Untert.	Handle-lower part			
	33			1117-1221-01	Führungsholm-Obert.	Handle-upper part			
	34			1117-1355-01	Schlüssel	Socket wrench			
	35			1117-1134-01	Motorbremsdraht	Engine brake cable			
	35			1117-1183-01	Motorbremsdraht	Engine brake cable			
	36			1117-1157-02	Behälterdeckel-schwarz	Grassbag cover-black			
	37			1117-1218-01	Behälter-Unterteil	Lower grass bag			
	38			1117-1148-01	Deckel	Cap			
	39			9948-0640-16	Schraube	Screw			
	40			9699-0025-02	Scheibe	Washer			
	41			9595-0258-00	Spannstift	Locating pin			
X	42			1111-9716-01	Messerhalterung	Blade holder			
X	43			1117-3221-01	Regulierbügel	OPC lever			
	44			9997-0830-16	Schraube	Screw			
	45			9678-0009-02	Schloßscheibe	Lock washer			
	46			1111-2927-01	Batteriehalter	Battery holder			
	47			1117-1116-01	Schnurhalter	Ropeholder			
	48			9799-0631-02	Mutter	Nut			

Vantage-Motor
Classic-Motor
Inkl. 17